

FPR210 PAINT STATION

To ensure you get the best performance from the FPR210 Paint Station, please read these tips before use.

PAINT SET UP

- It is recommended to use water based (emulsion) paint as this is ideal for home use, easier to thin and more environmentally friendly.
- Ensure that the paint is the right viscosity by using the viscosity cup and funnel to dilute the paint*. It should take approximately 18 seconds to run through the cup.
- There are 2 options to use the paint; use the bucket provided (ideal for thinning paint in) or the 2.5 litre paint tin will fit directly into the Paint Station.

* Different paint manufacturers have different consistency, therefore to ensure optimum product performance, some dilution may be required.

PRODUCT SET UP

- Open the top of the unit, place the paint tin or bucket inside, insert the tube cover and close the unit lid.
- Select whether 1 or 2 people will be using the machine with the lever at the front of the unit.
- Connect the tubes to the unit and the handle.
- Plug the product in.
- Finally, press the button on the side of the unit to 'forward'. Wait 2 minutes for the paint to circulate through the tubes and handle then start to use.

WHEN USING THE ROLLER

- Ensure that the flow control dial (located at the top of the handle) is initially set to minimum to prevent too much paint flowing through. Do not put too much paint on the roller initially.
- Adjust the flow control dial to the correct setting based on the viscosity of the paint.
- Use the trigger to allow paint to flow through the handle. Please note that the handle does not have to be depressed continually, only when more paint is required. It is advisable to turn the dial gradually until optimum flow is achieved.

WHEN USING THE CUTTING IN PADS

- Attach the correct pad.
 - Corner pad for the corner of walls
 - Cutting in pad for the bottom of wall/top of skirting board

- Ensure that the flow control dial (located at the top of the handle) is initially set to minimum to prevent too much paint flowing through.
- Adjust the flow control dial to the correct setting based on the viscosity of the paint.
- Note: This is a sponge, so do not apply too much in one go.

CLEANING THE PRODUCT

- When painting is complete, change the side button from 'forward' to 'reverse' to allow paint to be sucked from the handle and tubes back into the main container. Press the trigger to ensure all paint is removed from the tubes.
- When tubes have been emptied turn the unit off and remove the paint tin or bucket.
- Replace with warm soapy water and switch to 'forward' so that the water can circulate through the system, washing paint from the tubes. Repeat twice with clean water.
- Flush some of this warm water through the tubes and handle before attaching to an outside tap (if available) and flushing through at a higher pressure. Remember that the trigger needs to be pressed to allow water to flow through and clean.
- Disconnect Tubes and press valves at each end to release trapped water
- Wash the roller and cutting in pads in warm soapy water.

KEY FEATURES & BENEFITS

- It is a 2 in 1 machine. 1 or 2 people can use it at the same time, using both or either the roller and cutting in pads.
- Any brand of paint can be used with this product.
- Paint can be used direct from the original tin or the bucket provided.
- Fluid Technology is a system that continually mixes and circulates the paint for optimum consistency and flow.
- The roller is a standard 228mm/9 inches.
- 2.2 'metres squared' a minute can be painted.
- Easy clean with the tap adaptor and reversible pump.
- Ideal for painting interiors.